



Wind / Temperature Sensor wiring diagram

Part number: 480 1000 045



Mast mount 25-50mm dia.
 or Instromet mast kit
 Long 480 1000 096
 Short 480 1000 103
 Tile/slate clamp 480 1000 097



Red = +5V supply
 Yellow = Wind Direction input
 Black = Ground
 Blue = Wind Speed input
 Green = Temp input
 White = Temp input

Installation Instruction

Sensor wiring

The six core cable should be connected to the individual sensor via the terminal block on the sensor bracket. This can be accessed by removing the black cover, where a wiring colour identification label will be found.

Roof Top Wind/Temperature Sensor

This unit should be mounted on a mast of 25-50mm (1-2inches) in diameter, as high and as far away as possible from chimneys, roof peaks, buildings, trees and transmitter aerials which may cause wind turbulence or interference. Where possible the roof top wind sensor should be mounted at least 2 metres above roof peaks and be secured in position with the arm pointing accurately to the NORTH with the compass provided.

The cable from the roof top wind sensor should be run down to the junction box, making sure it is properly secured. Please note! This cable should not be run in close proximity to power or transmitter cables. If it is necessary to shorten the cable, please do this when connecting the cable to the display unit.

WARNING: Under no circumstances should the wind sensor junction box cover or the terminal block inside be sealed in any way as it is designed to breathe.

Troubleshooting Guide.

You've installed your Wind sensor and find that despite careful attention to detail, it does not work as expected. The following notes may assist in getting your Wind sensor working.

Nothing appears to work.

Check that the power supply is turned on at the wall socket. Check power cable correctly wired to the correct terminals in the Junction Box. If the lamps inside the unit are illuminated then the power to the instrument is correctly wired and working.

Wind Direction wrong

If Wind Direction gives the wrong reading, check that the wind sensor has been mounted to point North. If the pointer is permanently displaying a Northerly or North North East wind direction then the wind sensor is not connected to the instrument or is incorrectly wired. Note that if the wind sensor is incorrectly wired then neither wind speed nor direction will work.

Wind Speed not working

Check anemometer cups are turning freely and if so wiring is correct (particularly the *blue* wire from the Wind Sensor) and the cable not damaged.

Wind Sensor voltages

Supply voltage	Black – Red = 5V DC
Wind Speed	Black – Blue = 2.5V AC (with cups rotating)
Wind Direction	Black – Yellow = North = 0V or 4.5V DC East = 1.5V DC South = 2.5V DC West = 3.5V DC